

SIRIO GPS Satellite Guidance System

Through signals sent by geostationary satellites, **SIRIO** provides instructions so that the equipment will not pass over a previously treated area.

- Can be used for crop spraying treatments, sowing processes, etc.
- Can be positioned inside or outside the cab.
- **FREE** direct connection to GPS satellite network.
- Free “**SKYGUIDE**” exclusive software enables precision operation in zones where the correction signal is unavailable. No subscription fees for specific correction signals.
- Indication of course by means of LED bars.
- Multilingual alphanumeric display.
- Gives information on:
 - Misalignment
 - Track number
 - Tracks treated
 - Area treated
 - Speed
 - Steering angle.
- Alarm sounds when zones already treated are passed over, tracks are overlapped, satellite signal is lost, etc.
- Possibility of returning to last point treated at any given time.
- Choice of steering modes: Contour or Straight.
- 5Hz Leica Geosystems satellite receiver included.
- Free Firmware updates by personal computer.



The angle indicator displays the correction in degrees required to keep on an exact course

*The **SIRIO** display provides numerous messages and alarms in several languages.*

The lateral deviation bar signals when the equipment departs from the intended swath



Part No: 63520100

SIRIO GPS Satellite Guidance System




SIRIO comes with monitor, control panel, satellite receiver and connecting cable.

How SIRIO works


The machinery first traces the perimeter of the field to be treated. **SIRIO** collects all data and stores it into memory (up to 5 fields).

At the end of the circuit, it signals to the operator that he is nearing the initial track.

After marking points A and B of the straight line that will be used as a reference, the whole field can be treated in parallel equidistant tracks



During the process, **SIRIO** will give the operator instructions by means of LED bars and messages on the display.



Work can be carried out at different intervals because **SIRIO** is able to take the operator back to the exact point where previous treatments ended, and indicates the tracks that have already been treated.